

Index

Symbols

! commands 3-11
+ or - commands 15-6
? command 3-2, 3-10

Numerics

10/100 14-1, 14-6
10/100 auto-sensing ports 1-48, 1-53, 1-57,
1-62, 1-68, 1-72
10/100 command 13-2
10/100 ports 13-3, 13-6
10/100cfg command 1-53, 1-57, 1-62, 1-68,
13-3, 13-5
10/100vc command 1-53, 1-57, 1-62, 1-68, 13-6
802.1Q 13-1, 14-1
802.2 pass through 16-15, 17-32

A

aat command 28-34
ab command 5-8
addprtnl command 13-9
addvp command 17-5, 17-19, 17-28, 17-46,
17-61
translations 16-15
adjacency
definition for XMAP 19-2
ADM 36-25, 36-26
admin login 3-17, 6-2
aipxsr command 25-12
aisr command 23-15
any-to-any switching 16-1
application examples
OS-1032C 1-5
OS-2032 1-6
OS-3032 1-7
OS-3032E 1-7
OS-4016 1-8
OS-5024 1-9
ARP protocol 23-3
ARP server 26-22
ASCII terminal commands 3-3
at command 17-19

ATM

access modules 26-1
cell errors 26-25
Classical IP 28-10
discards 26-24
IPX routing 17-39
LAN Emulation 28-3
Point-to-Point Bridging 28-12
segment buffers 26-6
Segmentation and Reassembly (SAR) 26-6
statistics 26-23, 26-24, 26-26, 26-27, 26-28,
26-30
Trunking 28-22
VLAN clusters (X-LANE) 28-13
ATM access modules 26-1
ATM access ports
bandwidth groups 26-32
cell errors 26-25
configuring 26-4
discards 26-24
loopback mode 26-7
MBS 26-33
PCR 26-9, 26-33
PVCs 26-8
SCR 26-33
Segmentation and Reassembly (SAR) 26-6
statistics 26-23, 26-24, 26-26
traffic shaping 26-32
viewing 26-14
virtual channels 26-19
ATM address
creating 26-12
deleting 26-13
modifying 26-13
viewing 26-21
atm command 26-3
ATM Direct Mapped (ADM) Protocol 36-25,
36-26
ATM Point-to-Point Bridging 28-12
ATM port
DS3 36-17, 36-20, 36-21, 36-22, 36-28, 36-29,
36-30, 36-31
E3 36-23, 36-25, 36-26, 36-32, 36-33
number of services supported 28-1

- ATM switching
 - Maximum Burst Size (MBS) 26-33
 - Peak Cell Rate (PCR) 26-33, 26-34
 - Sustainable Cell Rate (SCR) 26-33
- ATM Trunking 28-22
- ATM uplinks
 - example 26-2
- atvl** command 18-19, 20-27
- authenticated group
 - as mobile group 17-5
 - configuring 17-27
- Authenticated Groups 17-1
- Authentication 17-1
- Authentication Management Console (AMC)
 - software 17-5
- auto-activated LANE ports
 - configuring 17-33
- autoencaps** command 16-34
- auto-sensing ports
 - see 10/100 auto-sensing ports
- auto-switch
 - diagram 17-30
 - timer 17-30
- Auto-Switch bridge mode 17-29
- AutoTracker
 - application examples 22-1
 - configuring policies 18-4
 - DHCP MAC address policy 18-3
 - DHCP policy 18-25
 - DHCP policy example 18-23
 - DHCP port policy 18-3
 - MAC address policy 18-2
 - menu 20-2
 - network address policy 18-2
 - policies 18-1, 20-3
 - port binding policy 18-2
 - port policy 18-2
 - protocol policy 18-2
 - user-defined policy 18-2
- AutoTracker policies
 - in mobile group 17-34
- avlbootpmode** command 24-1

B

- backbones 13-7
 - Ethernet 13-7
- backplane threshold 9-4
- Backup Power System (BPS) 1-81
- balanced T1 38-3
- bandwidth group 26-32

- Banyan Vines
 - translations for 16-12
 - VLAN for 20-31
- BECN 31-9
- BNC 38-3
- boot configuration A-1
- BOOTP relay 24-3
 - and authentication 24-4
- br** command 15-4, 17-19
- BRI. See ISDN, Basic Rate Interface
- bridge 15-6
- bridge forwarding table 15-7
- bridge mode 17-29
 - non-Ethernet default 17-29
 - optimized 17-29
 - Spanning Tree 17-29
- bridge port
 - statistics 15-13
- bridging
 - Frame Relay 31-12, 31-49
- bsadd** command 37-3
- bsdelete** command 37-10
- bsmodify** command 37-7

C

- CAM threshold 9-5
- camstat** command 7-23
- caplog** command 8-12
- cas** command 14-6, 14-8, 17-33, 28-16
 - ATM Trunking 28-22
 - Classical IP 28-24
 - Frame Relay bridging 31-49
 - Frame Relay routing 31-52
 - Frame Relay trunking 31-54
 - LAN Emulation 28-18
 - PTOP Bridging 28-26
 - VLAN Clusters 28-28
- cats** command 17-2, 17-15
- cb** command 5-8
- cd** command 17-63
- channelized DS3 38-2
- chassis summary 7-3
- chnlinfo** command 13-12
- Classical IP 28-24
 - ARP table 28-48
 - Group for 28-24
 - static entries 28-34
- Classical IP (CIP) 17-21, 17-38

- clear channel 38-40
 - logical port 38-40
- cli** command 3-3
- cmdlog** command 8-10
- command history 3-11
- Committed Information Rate (CIR)
 - Frame Relay 31-7
- configuration files 5-2
- conlog** command 8-11
- consumable resources 9-2
- cp** command 5-6
- cpis** command 36-33
- CPU threshold 9-5
- cratvl** command 20-4, 20-16, 20-31
- crechnl** command 13-8
- credit
 - transmit 17-30
- crgp** command 17-5, 17-21, 20-4
 - translations 16-15
- crmctl** command 21-5
- cut-through routing 29-2
- cva** command 26-12
- cvc** command 26-8

D

- das** command 14-12, 28-38
 - Frame Relay 31-58
- dat** command 28-39
- date 7-8
- datas** command 17-15
- Daylight Savings Time 7-12
- Daylight Savings Time (DST) 7-8
- db** command 5-8
- dbrmap** command 15-18
- debuglog** command 8-14
- def_group variable 17-11
- default group 17-11
- default VLAN 20-4, 20-5
 - routing 22-8
- defvl** command 20-5
- delechnl** command 13-10
- delprtchnl** command 13-11
- DES 10-4
- DHCP 24-3
 - and source routing 24-4
 - application example 18-23
 - overview 24-3

- policies 18-3
 - with non-DHCP clients 24-7
- DHCP client 18-24
- DHCP server 18-24
- diag login 3-17, 6-2
- diag user login 40-4
- diagnostics
 - configuring 40-16
 - configuring for Ethernet slots 40-17
 - displaying available tests 40-15
 - login 40-4
 - running 40-6
 - temperature masking 40-5
 - test cable schematics 40-18
- diagnostics sub-menu 3-2, 40-4
- digital services 35-2
- digital signal level X, see DSX
- Discard Eligibility
 - Frame Relay 31-8
- displaying Ethernet switch statistics 16-29
- DLCI 31-5
- DLCMI 31-22
- domain bridging
 - mapping table 15-18
- domain name servers 12-1
- DS0 38-2
- DS1 38-2
- DS1 channel 38-27
 - configuration and statistical parameters 38-37
 - statistics and errors 38-31, 38-33, 38-34, 38-36
- ds1clis** command 38-36
- ds1dcs** command 38-37
- ds1dlcs** command 38-33
- ds1dlis** command 38-34
- ds1dlts** command 38-31
- ds1mod** command 38-27
- DS2 38-2
- DS3 38-2
 - software 36-17, 36-20, 36-21, 36-22, 36-28, 36-29, 36-30, 36-31
- ds3** command 36-2
- DS3 port 38-13
 - statistical parameters 38-25
 - statistics and errors 38-19, 38-21, 38-22
- ds3clis** command 38-24
- ds3dcs** command 38-25
- ds3dlcs** command 38-21
- ds3dlis** command 38-22

- ds3dlts** command 38-19
- ds3dms** command 38-26
- ds3mod** command 38-13, 38-16, 38-40
- dslcs** command 36-15, 38-21, 38-33
- dslis** command 36-16, 38-22, 38-34
- dslts** command 36-13, 38-19
- dsmod** command 36-2
- dss** command 36-7
- DST 7-8
- DSX 38-2
- dt** command 7-8
- duplicate MAC addresses 7-22
- dva** command 26-13
- dvc** command 26-11
- dynamic LANE service
 - deleting 17-15
- dynamic LANE services 17-5, 17-15
- dynamic port assignment 17-2

E

- E1
 - fractional 30-2
 - framing 35-2
- E3
 - software 36-23, 36-25, 36-26, 36-32, 36-33
- eb** command 5-8
- echo** command 3-16
- edit** command 5-7
- edit commands tutorial 5-11, 5-12
- Egress Cache Table 29-20
- egress cache table 29-20
- ELAN
 - auto-activated 17-15, 17-33
- ELANs
 - multiple 28-20
- encapsulation 16-5
 - IP 16-5
 - IPX 16-5, 16-7
- error messages 39-5
- ESM-100C-12 13-3
- ethdef** command 16-24
- Ethernet
 - 10/100 ports 13-3
 - 802.1Q 13-1
 - auto-sensing ports 13-3
 - auto-switch bridge mode 17-29
 - backbones 13-7
 - default translations 16-16, 16-24

- duplex mode 13-6
- Ethertype translation 16-18
- high-density ports 13-5
- link mode configuration 13-5
- LLC translation 16-21
- OmniChannel 13-1
- path MTU discovery 23-36
- port mapping 17-67
- port mirroring 17-58
- port monitoring 17-62
- SNAP translation 16-19
- Ethernet 10/100 ports 13-6
 - auto-negotiation 13-6
 - configuring 13-3
- Ethernet modules
 - configuring tests 40-17
 - displaying switch statistics 16-29
- event 12-3
- events** command 12-5

F

- facility datalink 35-5
- Fast Ethernet
 - configuring 13-6
- FDDI
 - default translations 16-16, 16-25
 - LLC translation 16-21
 - SNAP translation 16-19
- FDDI raw 16-25
- fddidef** command 16-25
- FECN 31-10
- fiber optic
 - proper handling of cables 1-3, 2-3
- file** command 3-2, 5-1
- files 5-3
 - configuration 5-2
 - file name directory 5-3
 - flash memory 5-2
 - image 5-2
 - managing 5-1
 - required 5-2
- Filter Command. See UI Table Filtering
- flc** command 15-20
- flood limit 17-30
- flood limits
 - configuring 15-20
 - displaying 15-21
- fls** command 15-21

fping command 23-19
fr command 31-18
fradd command 31-28
 frame flooding 20-15
 Frame Relay
 access rate 31-21
 back-to-back configurations 31-2
 BECN 31-9
 bridging 31-12, 31-49
 cables 31-3, B-1
 CIR 31-7
 compression 31-4
 congestion control 31-7
 control signals 31-39
 Discard Eligibility 31-8
 DLCI 31-5
 DLCMI 31-22
 errors 31-41
 FECN 31-10
 IP routing 31-13
 IPX routing 31-16
 polling 31-22
 port configuration 31-19
 Routing Group 31-51
 self-configuration 31-6
 split clocking 31-21
 statistics 31-34
 translations 31-11
 trunking 31-17, 31-54
 viewing parameters 31-29
 Virtual Circuit 31-5, 31-12
 Virtual Circuit configuration 31-28
 virtual ports 31-12
 Frame Relay boards
 ipxsap command with, 25-10
 frame relay DLCI 38-64, 38-65
frclear command 31-46
frdelete command 31-32
frmodify command 31-19
frstatus command 31-34
frview command 31-29
fsck command 5-14, 7-20
 FTP
 commands 4-3
 FTP client 4-1
ftp command 4-3
 FTP commands
 ? 4-3
 ascii 4-3
 binary 4-3

 bye 4-3
 cd 4-3
 delete 4-3
 dir 4-3
 get 4-3
 hash 4-3
 lpwd 4-3
 ls 4-3
 put 4-3
 pwd 4-3
 quit 4-3
 remotehelp 4-3
 user 4-3
 FTP servers 4-1, 4-2
fwtl command 18-22, 20-30

G

generic service relays 24-18
 Giga I ASIC 14-5
 Giga II ASIC 14-5
 Gigabit 14-1, 14-5, 14-8
 GMAP
 configuring 19-11
 gap time 19-11
 update time 19-12
gmappgptime command 19-11
gmapholdtime command 19-12
gmapls command 19-13
gmapst command 19-11
gmapupdttime command 19-12
gmcfg command 17-11, 20-2
gmstat command 20-2
gp command 17-19, 17-40
 Group 17-1
 authenticated 17-1
 deleting 17-45
 flood limits 15-21
 mobile 17-1
 non-mobile 17-1, 17-17
 port assignment to 17-2
 viewing 17-40
 group
 authenticated 17-27
 changing parameters 17-42
 CIP 17-21, 17-38
 creating 17-20
 IP address 17-22
 IP routing in 17-22

- mobile 17-5, 17-27
 - WAN routing 17-21, 17-35
- group mobility 17-2
 - enabling switch-wide 17-11
- Group multiplexing 28-8

H

- hardware diagnostics 40-1
- Hardware Routing Engine (HRE-OSTK) 1-1, 1-80
 - OS-5024 switches 1-72
- hdcfg** command 9-2
- hdstat** command 9-6, 9-7
- Health MIB 9-1
 - management menu 9-1
 - resource thresholds 9-2
- Hello messages
 - and XMAP 19-2
- help** command 3-2
- history** command 3-11
- hmstat** command 9-8
- hpstat** command 9-8
- hreset** command 9-9

I

- ib** command 5-9
- ICMP protocol 23-3
- ICMP statistics and errors 23-17
- icmps** command 23-17
- image files 5-2
- imgcl** command 5-5
- info** command 7-6
- Ingress Cache Table 29-19
- interface** command 3-2
- Interim Local Management Interface (ILMI) 26-5, 26-15
- Interswitch Protocols (XIP) 19-1
 - submenu 19-1
- Inverse ARP 31-13
- IP
 - abbreviated address format 3-13
 - address 4-2
 - BOOTP relay 24-3
 - DHCP 24-3
 - framing type 17-24
 - RIP mode 17-23

- IP address
 - changing in group 17-43
- ip** command 23-7
- IP protocol 23-3
- IP RIP Filters
 - adding "global" filters 23-28
 - adding specific filters 23-29
 - configuring 23-28
 - deleting filters 23-31
 - displaying all filters 23-32
 - displaying global filters 23-33
 - displaying specific filters 23-33
 - filter precedence 23-30
- IP Routing
 - adding an IP address to ARP table 23-9
 - adding IP static routes 23-15
 - Address Resolution Protocol 23-3
 - flushing the RIP Routing Table 23-27
 - Internet Control Message Protocol 23-3
 - Internet Protocol 23-3
 - Open Shortest Path First Protocol 23-2
 - PING command 23-19
 - PINGing a host 23-19
 - removing IP static routes 23-16
 - Routing Information Protocol 23-2
 - Simple Network Management Protocol 23-3
 - TELNET protocol 23-3
 - tracing an IP route 23-27
 - Transmission Control Protocol 23-3
 - User Datagram Protocol 23-3
 - viewing ICMP statistics and errors 23-17
 - viewing IP statistics and errors 23-12
 - viewing RIP statistics and errors 23-22
 - viewing TCP statistics 23-23
 - viewing the Address Translation Table 23-8
 - viewing the IP routing table 23-14
 - viewing the IP-to-MAC Table 23-34
 - viewing the TCP Connection Table 23-25
 - viewing the UDP listener table 23-21
 - viewing UDP statistics and errors 23-20
- IP routing 17-22
- ipf** command 23-32
- ipmac** command 23-34
- ipr** command 23-14
- ips** command 23-12
- IP-to-MAC Table
 - displaying all entries 23-34
 - displaying specific entries 23-35
 - flushing entries 23-35

- IPX
 - address mapping 16-9
 - routing over ATM 17-39
 - Token Ring 16-14
 - triggered RIP and SAP 17-37
 - VLANs 22-4, 22-7
 - ipx** command 25-4
 - IPX RIP
 - description of protocol 25-2
 - IPX RIP/SAP Filtering
 - adding global filters 25-18
 - adding specific filters 25-19
 - configuring NetWare for WAN links 25-33
 - default setting of filters 25-17
 - deleting filters 25-21
 - displaying all filters 25-22
 - displaying global filters 25-23
 - displaying specific filters 25-23
 - filter precedence 25-24
 - uses for filters 25-17
 - IPX routing
 - adding an IPX static route 25-12
 - configuring IPX Serialization Packet Filtering 25-25
 - configuring IPX Watchdog Spoofing 25-27
 - configuring NetWare for WAN links 25-33
 - configuring SPX Keepalive Spoofing 25-29
 - disabling IPX Router Complex 25-14
 - displaying IPX Routing Table 25-5
 - enabling IPX Router Complex 25-14
 - flushing RIP/SAP tables 25-14
 - GNS Output filters 25-17
 - PINGing an IPX node 25-15
 - removing IPX static routes 25-13
 - RIP Input filters 25-17
 - RIP Output filters 25-17
 - RIP/SAP Filters
 - configuring** 25-17
 - SAP Input filters 25-17
 - SAP Output filters 25-17
 - the IPX submenu 25-4
 - viewing IPX statistics 25-8
 - viewing SAP Bindery 25-10
 - IPX Serialization Packet Filtering
 - configuring** 25-25
 - IPX static routes
 - removing 25-13
 - IPX Watchdog Spoofing
 - configuring** 25-27
 - ipxdrt** command 25-38
 - ipxext** command 25-37
 - ipxf** command 25-22
 - ipxfilter** command 25-18
 - ipxflush** command 25-14
 - ipxoff** command 25-14
 - ipxping** command 25-15
 - ipxr** command 25-5
 - ipxs** command 25-8
 - ipxsap** command 25-10
 - ipxserialf** 25-25
 - ipxserialf** command 25-25
 - ipxspoof** 25-27
 - ipxt** command 25-35
 - ipxtimer** command 25-35
 - ISDN
 - Basic Rate Interface (BRI) 30-2
 - isdn** command 34-3
 - ISDN Ports
 - accessing the ISDN menu 34-3
 - deleting an ISDN configuration entry 34-5
 - displaying ISDN configuration entry status 34-7
 - modifying an ISDN configuration entry 34-4
 - viewing an ISDN configuration entry 34-6
 - isdnd** command 34-5
 - isdnm** command 34-4
 - isdns** command 34-7
 - isdnv** command 34-6
- ## K
- kill** command 3-21
- ## L
- LAN Emulation 28-3, 28-20, 28-45
 - back-off timers 28-6
 - BUS 28-43
 - LECS 28-43, 28-44
 - LES 28-43
 - Token Ring 28-4
 - LAN Emulation Clients, see LEC
 - LAN Emulation, see LANE
 - LANE 29-6
 - dynamic 17-5

- LANE (ATM)
 - default translations 16-17
 - Ethertype translation 16-18, 16-22
 - SNAP translation 16-20
- LANE Service Menu (LSM) 27-4
- layer 3 forwarding engine 29-4
- lb** command 5-9
- LE_ARP table 28-45
- learning 16-35
- LEC
 - Token Ring 28-4, 28-45
- LECS
 - adding ELANs to the, 27-16
 - adding policies to ELANs in the, 27-19
 - creating a, 27-12
 - displaying ELANs in the, 27-41
 - displaying policies assigned to an ELAN 27-42
 - displaying statistics for the, 27-38
 - displaying the configuration of the, 27-40
 - displaying the status of the, 27-37
- LEDs
 - Ethernet port LEDs 1-77
 - management LEDs 1-76
 - OS-1024 and OS-4024 Ethernet port LEDs 1-79
 - OS-1024 and OS-4024 management LEDs 1-78
- LES/BUS Pair
 - configuration overview 27-5
 - creating a, 27-7, 27-8
 - displaying LE Client information for a, 27-35
 - displaying registered MAC addresses for a, 27-33
 - displaying statistics for a, 27-25
 - displaying the configuration of a, 27-31
 - displaying the registered route descriptor for a, 27-34
 - displaying the status of a, 27-23
- Line Interface Unit (LIU) 35-5, 35-9
- link** command 33-2
- linkadd** command 33-3, 33-4
- linkdelete** command 33-11
- linkmodify** command 33-9
- linkstatus** command 33-15
- linkview** command 33-12
- LLC 16-6, 16-21
- load** command 4-4

- logical port
 - clear channel 38-40
 - configuration 38-38, 38-40
 - configuration and statistics 38-44
 - protocol configuration 38-47, 38-50
 - protocol configuration and statistics 38-54, 38-58
 - statistics and errors 38-46, 38-63
- login accounts 3-17, 6-2
- logout 3-2
- logout** command 3-2
- lookup** command 3-10
- lpadd** command 38-38
- lpcls** command 38-46
- lpdel** command 38-43
- lpfradd** command 38-64
- lpfrdel** command 38-65
- lpmod** command 38-40
- lppcls** command 38-63
- lppmod** command 38-47, 38-50
- lppview** command 38-54, 38-58
- lpview** command 38-44
- ls** command 4-4, 5-2
- lslb** command 27-22
- lsmcfg** command 27-5

M

- m013** command 38-10
- m013cas** command 38-69
- m013cfgdel** command 38-74
- m013das** command 38-71
- m013mas** command 38-73
- m013vas** command 38-71
- MAC 15-15, 15-16
- MAC devices
 - VLAN membership 18-22, 20-30
- main menu 3-2
- Maintenance Data Link, see MDL
- map** command 26-4, 26-24
- mas** command 14-10, 28-30
 - ATM Trunking 28-31
 - Classical IP 28-32
 - Frame Relay 31-57
 - LAN Emulation 28-30
 - PTOP Bridging 28-35
 - VLAN Clusters 28-36
- maskta** command 40-5

- Maximum Burst Size
 - ATM access ports 26-33
 - MBS 26-33
 - mbwg** command 26-32
 - mcvl** command 21-13
 - MD5 10-4
 - MDL 38-17, 38-26
 - media access control - see MAC
 - memory management 7-19
 - memory threshold 9-5
 - memstat** command 7-19
 - mobile group 17-1, 17-5
 - aging out devices 17-11
 - AutoTracker policies 17-34
 - configuring 17-27
 - def_group 17-11
 - default group 17-11
 - dynamic LANE 17-15
 - dynamic port assignment 17-5
 - Ethernet and Token Ring ports 17-2
 - move_from_def 17-12
 - move_to_def 17-11
 - multiple 17-2
 - policies 18-1, 18-20
 - ports in 17-5
 - primary group 17-12
 - static port assignment 17-5
 - viewing 18-19
 - modatvl** command 18-6, 18-18, 20-24
 - modmcvl** command 21-9, 21-12
 - modvl** command 17-23, 17-42, 20-4, 20-19
 - modvp** command 17-47, 17-61
 - translations 16-15
 - move_from_def variable 17-12
 - set in mpm.cmd 17-12
 - move_to_def variable 17-11
 - MPC 29-4
 - MPC components 29-4
 - mpccfg** command 29-10, 29-11
 - MPM Module
 - serial port 7-14
 - MPOA 29-1
 - configuring a client 29-11
 - egress cache table 29-20
 - functionality 29-1
 - ingress cache table 29-19
 - management menu 29-10
 - requirements 29-4
 - viewing client status 29-14
 - viewing servers 29-21
 - viewing statistics 29-15
 - MPOA Client, see MPC
 - MPOA Network 29-8
 - MPOA Server, see MPS
 - MPS 29-5
 - MPS components 29-5
 - MTU 23-36
 - multicast claiming 7-25
 - Multicast VLANs 20-1, 21-1
 - creating 21-4
 - deleting 21-11
 - device assignment in 21-2
 - frame flooding in 21-3
 - modifying 21-9
 - multicast addresses 21-6
 - multicast claiming, compared 21-2
 - policies 21-12
 - recipients 21-1, 21-7
 - viewing 21-13
 - multicast VLANs
 - multiple spanning tree 14-3
 - multiple user sessions 3-18
 - Multi-Protocol Over ATM, see MPOA
 - mva** command 26-13
 - mvc** command 26-11
- ## N
- names** command 12-1
 - nb** command 5-9
 - net** command 37-2
 - NetBIOS relays 24-10
 - network address policy 20-7
 - precedence 18-2
 - Network Time Protocol 10-1
 - networking** command 3-2, 23-6
 - newfs** command 5-15, 7-21
 - Next Hop Clients, see NHC
 - Next Hop Resolution Protocol, see NHRP
 - Next Hop Server, see NHS 29-5
 - NHC 29-6
 - NHRP 29-6
 - noecho** command 3-16
 - non-Ethernet ports 17-29
 - non-mobile group 17-1, 17-17
 - ntaccess** command 10-5
 - ntaccess** command 10-36
 - ntadmin** command 10-5, 10-33

ntconfig command 10-5
ntinfo command 10-5
ntinfo command 10-15
NTP
 advertised precision 10-14
 client/server 10-8
 client/server authentication 10-9
 current leap second 10-30
 event timer subsystem 10-28
 I/O subsystem 10-27
 key ID 10-34
 key type 10-35
 list of peers 10-15
 local server information 10-21
 local server statistics 10-23
 loop filter information 10-26
 packet count statistics 10-29
 peer association 10-12
 peer associations 10-14
 peer memory usage 10-26
 peer summary information 10-16
 primary receive timeout 10-33
 reset subsystem counters 10-28
 server statistics 10-24
 specify password 10-34
 system flag 10-35
 trusted list 10-37
 version number 10-20
ntpaddpeer command 10-12
ntpaddserv command 10-13
ntpauth command 10-38
ntpbcast command 10-13
ntpckey command 10-37
ntpcres command 10-39
ntpctlk command 10-37
ntpctlstat command 10-29
ntpctrap command 10-41
ntpdelay command 10-33
ntpdisable command 10-35
ntpdkey command 10-38
ntpdres command 10-41
ntpdtrap command 10-42
ntpenable command 10-35
ntpiconfig command 10-6
ntpiconfig command 10-8
ntpinfo command 10-21
ntpio command 10-27
ntpkeyid command 10-34
ntpkeytype command 10-35
ntpleap command 10-30

ntploop command 10-26
ntplpeers command 10-15
ntpmem command 10-26
ntpmlist command 10-31
ntpmon command 10-31
ntpmres command 10-41
ntppasswd command 10-34
ntppeers command 10-16
ntpprec command 10-14
ntppreset command 10-28
ntppstat command 10-24
ntpreqk command 10-36
ntpreset command 10-28
ntpshowpeer command 10-18
ntpstat command 10-23
ntptimeo command 10-33
ntptimer command 10-28
ntpunconfig command 10-14
ntpvers command 10-20
ntpvkey command 10-37
ntpvres command 10-40
ntpvtrap command 10-42
ntstats command 10-5, 10-23

0

OmniChannel 13-1, 13-7
 creating 13-8
 Ethernet 13-7
 ports 13-9
 primary/secondary ports 13-11
OmniStack
 1024C 1-11
 1024CF 1-20
 1024F 1-15
 1032C 1-25
 1032CF 1-33
 1032F 1-29
 2032 1-37
 3032 1-41
 3032E 1-45
 4016 1-48
 4024C 1-52
 4024CF 1-61
 4024F 1-56
 4024G 1-66
 5024 1-72
 application examples 1-5

- DHCP 24-3
 - slot conventions 1-10, 31-1
- OmniSwitch 17-1
- optimized bridge mode 17-29
- OSASM2-155FM/FS-1 30-10
- OSASM2-155FM-1 2-9
- OSASM2-155FS-1 2-9
- OSASM2-155FSH-1 2-9
- OSASM2-155RFM-1 2-12
- OSASM2-155RFS-1 2-12
- OSASM2-622RFM-1 2-15
- OSASM2-622RFS-1 2-15
- OSASM2-DS3 2-18
- OSASM2-E3 2-18
- OSESM-100C-4 2-5
- OSESM-100FM/FS-2 30-7
- OSESM-100FM-2 2-7
- OSESM-100FS-2 2-7
- OSGSM-FM-2 2-20
- OSGSM-FS-2 2-20
- OSPF protocol 23-2
- OSWSM
 - access rate 30-18, 30-27
 - back-to-back configuration 30-5
 - back-to-back configurations 30-5
 - port configuration 30-18
 - split clocking 30-20
 - statistics 30-30
 - viewing parameters 30-23
- OSWSM-M013 module 38-1
 - application examples 38-4
 - configuration 38-74
 - configuration overview 38-8
 - DS1 channel 38-27
 - DS1 channel configuration and statistical parameters 38-37
 - DS1 channel statistics and errors 38-31, 38-33, 38-34, 38-36
 - DS3 port 38-13
 - DS3 port statistical parameters 38-25
 - DS3 port statistics and errors 38-21, 38-22
 - DS3 port using C-Bit Parity 38-16
 - DS3 port statistics and errors 38-19
 - frame relay DLCI 38-64, 38-65
 - logical configuration 38-11
 - logical port 38-43
 - logical port configuration 38-38, 38-40
 - logical port configuration and statistics 38-44

- logical port protocol configuration 38-47, 38-50
- logical port protocol configuration and statistics 38-54, 38-58
- logical port statistics and errors 38-46, 38-63
- management menu 38-10
- physical configuration 38-11
- router interface configurations 38-67
- router interfaces 38-66, 38-68
- service configuration 38-71, 38-73
- services 38-69, 38-71
- supported physical interfaces 38-3
- output translations 16-36

P

- password 3-17, 6-2
 - changing 6-2
- path MTU discovery 23-36
- PCR 26-33
- Peak Cell Rate
 - ATM access ports 26-33
- Physical Layer Convergence Protocol (PLCP)
 - 36-23, 36-32, 36-33
- ping** command 23-19
- pin-outs 1-91
- PLCP 36-23, 36-32, 36-33
- pmapcr** command 17-19
- pmapdel** command 17-19
- pmapmod** command 17-19
- pmapv** command 17-19
- pmcfg** command 17-63
- pmdelete** command 17-65
- pmon** command 17-64
- pmpause** command 17-65
- pmstat** command 17-66
- PMTU 23-36
- Point-to-Point Protocol (PPP)
 - accessing the PPP menu 32-5
 - adding a PPP entity 32-8
 - deleting a PPP entity 32-20
 - displaying PPP entity status 32-17
 - modifying a PPP entity 32-13
 - setting global parameters 32-6
 - viewing PPP entity configurations 32-14
- policies
 - AutoTracker 18-1
 - DHCP example 18-23
- policy
 - configuring 18-4

- DHCP 18-25
- DHCP MAC address 18-3
- DHCP port 18-3
- IP 20-7
- IPX 20-7
- MAC address 18-2
- network address 18-2, 20-7
- port 18-2, 20-9
- port binding 18-2
- protocol 18-2
- user-defined 18-2
- port mapping 17-19
 - example 17-67
 - operation of 17-68
 - relationship to policies 17-67
 - subset of ports 17-68
- port mirroring 17-32, 17-58
 - disabling 17-61
 - enabling 17-61
 - operation of 17-58
 - RMON probe 17-59
- port monitoring
 - menu 17-62
 - starting a session 17-64
 - statistics 17-66
- port monitoring resources 17-63
- port policies
 - with VAP 19-9
- port policy 20-9
 - backbone connections 20-12
 - inactive VLANs 20-12
 - silent stations 20-12
 - usefulness 20-12
- port tests
 - cabling 40-9, 40-18
- ports 17-51
 - assignment to Group 17-2
 - Frame Relay 31-1
 - information 17-51
 - spanning tree 15-29
 - statistics 17-54
 - translations 16-28
- power cords 1-90
- power supplies 1-85
- power supply
 - installing 1-85
 - removing 1-86
- ppp** command 32-5
- pppadd** command 32-8
- pppdelete** command 32-20

- pppglobal** command 32-6
- pppmodify** command 32-13
- pppstatus** command 32-17
- pppview** command 32-14
- probes 12-3
- probes** command 12-4
- prty_disp** command 17-19
- prty_mod** command 17-19
- PTOP Bridging 28-26
- PVC
 - deleting 26-11
 - modifying 26-11
- PVCs
 - ATM access 26-5
 - configuring 26-8
- pw** command 3-10, 6-2
- pwd** command 5-2

R

- rb** command 5-10
- reboot 6-3
 - see also boot
- reboot** command 6-3
- receive threshold 9-3
- re-executing commands 3-11
- reg_port_rule variable 20-9
- relayc** 24-2
- relayc** command 24-1
- relays** command 24-22
- remote trunking stations 15-17
- res** command 12-1
- resource thresholds 9-2
- riadd** command 38-66
- ridel** command 38-67
- rimod** command 38-67
- RIP protocol 23-2
- ripflush** command 23-27
- rips** command 23-22
- ripxsr** command 25-13
- risr** command 23-16
- riview** command 38-68
- rm** command 4-4, 5-4
- rmatvl** command 20-4, 20-26
- rmgp** command 17-45
- rmmcvl** command 21-11
- RMON 12-3
- rmvp** command 17-48

router interface 38-66, 38-68
 configuration 38-67
routing 16-1
 default VLAN 22-8
 Frame Relay 31-51

S

sampling interval 9-6
SAP
 description of protocol 25-2
SAP Bindery
 viewing the, 25-10
sc command 7-3
SC connectors
 proper handling 1-3, 2-3
SCR 26-33
Search Command. See UI Table Filtering
seclog command 8-14
security 6-1
security command 3-2
segment buffers
 relation to Virtual Circuits 26-6
Segmentation and Reassembly (SAR) 26-6
selgp command 15-6
ser command 4-4, 7-14
serial port 7-14
 parameters 7-14
service configuration
 WSX-M013 module 38-71, 38-73
services 28-1
 Classical IP 28-10
 LAN Emulation 28-3
 PTOP Bridging 28-12
 VLAN Clusters 28-37
 WSX-M013 module 38-69, 38-71
services command 3-2, 28-15
Service-Specific Connection Oriented
 Protocol (SSCOP) 26-15
si command 7-4
single spanning tree 14-3
slot command 7-16
slot designations 1-10, 31-1
slot table 7-16
SNAP 16-6, 16-19
SNMP protocol 23-3
SNMP statistics 11-7
SNMP traps 11-7
snmps command 11-7
software
 switch 5-3
source routing
 and DHCP 24-4
 parameters 15-33, 15-36
 virtual rings 15-33
Spanning Tree 17-29
 non-mobile group 17-18
spanning tree 15-27
 parameters 15-24, 15-27, 15-31
 ports 15-29
SPX
 description of protocol 25-2
SPX Keepalive Spoofing
 configuring 25-29
 SPX-Packet tolerance counting 25-29
spxspoo 25-29
srs command 15-36
static bridge address 15-12
 configuring 15-9
static port assignment 17-2
static routes
 adding IP 23-15
 removing IP 23-16
statistics
 module level 9-8
 port level 9-8
 port monitoring 17-66
 resetting 9-9
 switch level 9-6
STATUS ENQUIRIES
 Frame Relay 31-6, 31-22, 31-23
summary command 3-2, 7-1
Sustained Cell Rate
 ATM access ports 26-33
SVCs
 ATM access 26-5
swch command 16-28, 16-29
switch
 software 5-3
switch command 3-2, 16-23
switch menu 16-23
switch software
 Boot prompt 4-5
 loading with FTP 4-2
 loading with ZMODEM 4-4
swlogc command 8-6
syscfg command 7-22
syslog command 8-2
systat command 7-17

- system boot A-2
 - commands 4-6
 - See also boot

- system** command 3-2
- system description 7-22
- system info 5-13, 7-5
- system menu 5-13, 7-5
- system prompt 3-4
- system statistics 7-17
- system variables 7-2

T

- T1
 - fractional 30-2
 - framing 35-2
- T1/E1 menu 35-3
- T1/E1 ports 35-1
 - alarms 35-11
 - Extended Superframe 35-2, 35-4
 - facility datalink 35-5
 - line coding 35-5, 35-9
 - Line Interface Unit (LIU) 35-5, 35-9
 - loopback 35-6, 35-10
 - remote statistics 35-20
 - signaling 35-6, 35-10
 - statistics 35-17
 - Superframe 35-2, 35-4
 - yellow alarms 35-7
- Table Filtering. See UI Table Filtering
- task utilization statistics 7-18
- taskstat** command 7-18
- TCP protocol 23-3
- tcpc** command 23-25
- tcps** command 23-23
- te** command 35-3
- technical support 39-1
- telcs** command 35-18
- telis** command 35-19
- TELNET command
 - using 23-26
- telnet** command 23-26
- telts** command 35-17
- temod** command 35-4, 35-8
 - configuring a T1 port 35-4
 - configuring an E1 port 35-8
- temperature sensor 7-17
- tercs** command 35-21
- teris** command 35-21

- terts** command 35-20
- tes** command 35-11, 35-13, 35-15
 - viewing a T1 port 35-13
 - viewing an E1 port 35-15
- test** command 40-6
- testcfg** command 40-16
- testdisp** command 40-15
- time 7-8
- time slot 35-2
- time zone 7-8
- Timezone 7-9
- Token Ring
 - default translations 16-17, 16-26
 - LEC 28-4, 28-45
- traceroute** command 23-27
- Traffic Descriptors
 - Maximum Burst Size (MBS) 26-33
 - Peak Cell Rate (PCR) 26-33, 26-34
 - Sustainable Cell Rate (SCR) 26-33
- traffic shaping
 - ATM access ports 26-32
 - bandwidth groups 26-32
- translations 16-1
 - ATM LANE 16-17
 - automatic 16-34
 - default options 16-15
 - Ethernet 16-16
 - Ethertype 16-18
 - FDDI 16-16
 - LLC 16-21
 - SNAP 16-19
 - Token Ring 16-17
- transmission states
 - XMAP 19-3
- transmit credit 17-30
- transmit/receive threshold 9-3
- traps
 - configuring 11-2
- trdef** command 16-26
- troubleshooting 39-1
 - chassis error messages 39-7
 - hardware problems 39-4
 - module connection error messages 39-8
 - serial port error messages 39-6
 - shutdown error messages 39-5
 - software problems 39-2
 - startup error messages 39-5

U

- UDP 23-3
- UDP relay 24-1
- udpl** command 23-21
- udps** command 23-20
- UI Table Filtering 3-23
 - Filter Command 3-26
 - combining Search Command with 3-28
 - more** mode and 3-23
 - Search Command 3-24
 - combining Filter Command with 3-28
 - more** mode and 3-23
 - renewing a search 3-25
 - wildcards and 3-30
- uic** command 3-4–3-9, 3-15, 7-5
- Universal Serial Port 30-2
- Universal Time Coordinate (UTC) 7-8
- uplink
 - ATM 155 Mbps 2-9
 - ATM 44.736 and 34.368 Mbps 2-18
 - Ethernet 10/100 2-5
 - Ethernet 100BaseFx 2-7
 - Gigabit Ethernet 2-20
 - redundant ATM 155 Mbps 2-12
 - redundant ATM 622 Mbps 2-15
- uplink submodules 2-1
 - installing 2-2
 - OSASM2-155FM-1 2-9
 - OSASM2-155FS-1 2-9
 - OSASM2-155FSH-1 2-9
 - OSASM2-155RFM-1 2-12
 - OSASM2-155RFS-1 2-12
 - OSASM2-622RFM-1 2-15
 - OSASM2-622RFS-1 2-15
 - OSASM2-DS3 2-18
 - OSASM2-E3 2-18
 - OESM-100C-4 2-5
 - OESM-100FM-2 2-7
 - OESM-100FS-2 2-7
 - OSGSM-FM-2 2-20
 - OSGSM-FS-2 2-20
- User Interface 3-1, 3-3
- user login 3-17, 6-2
- USP. See Universal Serial Port.
- UTC 7-8

V

- VAP
 - configuring 19-9
 - databases 19-8
 - relation to port policies 19-9
- vap** command 26-14, 26-17
- vas** command 14-11, 28-40
 - Frame Relay 31-56
- vat** command 28-48
- vbwg** command 26-34
- vcrs** command 26-28
- vcs** command 26-27
- vcts** command 26-30
- ve** command 17-56
- velan** command 27-41
- verbose 3-8
- vi** command 16-22, 17-51
- via** command 17-49
- viatrl** command 18-20, 20-28
- view** command 5-6
- vigl** command 17-13
- vimcrl** command 21-14, 21-15
- virtual channel
 - statistics 26-27, 26-28, 26-30
- virtual channel connection
 - modifying 26-11, 26-13
- virtual channels
 - status 26-20
 - viewing 26-19
- virtual ports 17-17
 - adding 17-46
 - deleting 17-48
 - errors 17-56
 - format 17-31
 - information on 17-49
 - modifying 17-47
 - statistics for 17-51, 17-54
 - VLAN membership 20-29
 - VLAN/group membership 18-21
- virtual router ports 20-19
 - creating 17-22
- vivl** command 18-21, 20-29
- VLAN Advertisement Protocol
 - see VAP
- VLAN Clusters 28-28
 - 1483 encapsulation 28-29
- vlan** command 3-2, 17-19

- VLAN policies
 - deleting 20-25, 21-10
 - modifying 20-26, 21-11
 - viewing 18-20, 20-28, 21-14
- VLANs 17-17, 20-1
 - application examples 22-1
 - backbone 22-10
 - Banyan Vines 20-31
 - bridges 15-4
 - creating 20-16
 - default 20-4
 - deleting 20-26
 - deleting policies in 20-25, 21-10
 - frame flooding in 20-15
 - IP routing in, 23-4
 - IPX networks 22-4, 22-7
 - logical policies 22-2
 - modifying 20-24
 - multicast 21-1
 - network address policies 22-2
 - policies 18-2, 20-3
 - port policy 20-9, 20-18
 - router ports 20-15
 - router traffic in 20-7
 - secondary traffic 20-6
 - translated frames 22-7
 - trunking 28-8
 - viewing 18-19, 20-27
- vlap** command 19-9
- vlat** command 28-45
- vlb** command 27-23
- vlbc** command 27-31
- vlbs** command 27-25
- vlec** command 27-32, 27-35
- vlecs** command 27-37
- vlecsc** command 27-40
- vlecscs** command 27-38
- vlrs** command 26-24
- vls** command 26-23
- vlts** command 26-26
- vmac** command 27-33
- vmpec** command 29-10, 29-14
- vmpecs** command 29-10, 29-19
- vmpecs** command 29-10, 29-21
- vmpecst** command 29-10, 29-15
- vpis** command 36-28
- vpolicy** command 27-42
- vps** command 36-17
- vs** command 17-54

- vss** command 28-41, 28-42, 28-46, 28-49
- vva** command 26-21
- vvc** command 26-19

W

- wan** command 30-17
- WAN Links
 - accessing the LINK menu 33-2
 - adding a link record 33-3
 - deleting link records 33-11
 - displaying link status 33-15
 - modifying a link record 33-9
 - viewing link records 33-12
- WAN routing 17-21, 17-35
- WAN Switching Module (WSM)
 - cables B-1
- wb** command 5-10
- who** command 3-19
- wpmmodify** command 30-17
- wpstatus** command 30-30
- wpview** command 30-23
- write** command 3-20
- WSM-FT1/E1 35-1

X

- X802.1Q 14-1, 14-3
- X-LANE 28-13
- xlat** command 23-8
- XMAP
 - adjacency 19-2
 - and remote switches 19-4
 - common transmission time 19-7
 - configuring 19-5
 - discovery transmission time 19-6
 - transmission states 19-3
 - well-known MAC address 19-3
- xmapcmntime** command 19-7
- xmapdisctime** command 19-6
- xmapls** command 19-5
- xmapst** command 19-5

Z

- ZMODEM 4-1, 4-4, A-1