

Algorithms for Radio Networks

MIMO

University of Freiburg Technical Faculty Computer Networks and Telematics Prof.Christian Schindelhauer





Smart Antennas

Alternative terms


- Adaptive Array Antennas
- Multiple Input Multiple Output (MIMO)

Prinziple

- Multiple antennas are coordinated manner
 - used to improve reception or transmission of behavior
 - to allow additional features

Features

- Directional receivers
- Directional senders
 - better path loss exponent
 - spatial multiplexing
 - MIMO communikation




DOA Estimation

With two antennas, one can determine the receive direction (DOA)

 Paulraj, Roy, Kailath, Estimation of Signal Parameters via Rotational Invariance Techniques- ESPRIT, Nineteeth Asilomar Conference on Circuits, Systems and Computers, 1985, 83-89


Idea:

 The signals arrive at different times to the antennas. By parallel testing of overlays can be candidates for the angle of incidence findenn



Beam forming

- Simulation of receiving or transmitting antenna behavior of any of Smart Antennas
- Active
 - By suitably chosen time shift, receipt of signals at the antennas will transmit the desired direction preference
 - Other directions only increase only background noise
 - Applications: radar, mobile communications, MIMO
- Passive
 - As with the DOA-detection, the signals are delayed and superimposed
 - Applications: Microphones, MIMO




Smart Antennas Combinations

- SISO (Single Input Single Output)
 - Classic radio model
- SIMO (Single Input Multiple Output)
 - · Classical transmitter with an antenna
 - Antenna array at the receiver
 - Different channels can be received in parallel from different angles

MISO (Multiple Input Single Output)

- Antenna array as a transmitter
- Individual recipients (groups) can be individually reached
- MIMO (Multiple Input Multiple Output)
 - Directed (and parallel) communication between the transmitter and receiver possible
 - Efficient utilization of the medium



Motivation for MIMO

Increase of SINR by

- more sender antennas
- more receiver antennas
- Multipaths
 - · are used for increasing the channel capacity
- Capacity
 - grows with the complexity of the environment
 - with the number of senders and receivers

MIMO Free Space Model

- The message m is modulated as x(t) over a carrier
 - i.e. $s(t) = x(t) e^{j2\pi ft}$
- Electric field is described by the signal
 - ~ force on charged particles
 - adds up (superposition)
 - decreases proportional to the distance
- Power is proportional to the square of the electric field

SINR =
$$\frac{\left|\sum_{\text{sender } i \text{ receiver } k} s_i \cdot \frac{e^{j|u_i - v_k|}}{|u_i - v_k|} \cdot g_k\right|^2}{\sum_{\text{receiver } k} |g_k|^2 \left(N + \sum_{\text{interference } i} \frac{P'_i}{|w_i - v_k|^2}\right)}$$

MIMO Free-Space SINR

 $\operatorname{SINR} = \frac{\left|\sum_{\text{sender } i \text{ receiver } k} s_i \cdot \frac{e^{j|u_i - v_k|}}{|u_i - v_k|} \cdot \frac{y_k}{|u_i|^2}\right|}{\sum_{\text{receiver } k} |g_k|^2 \left(N + \sum_{\text{interference } i} \frac{P'_i}{|w_i - v_k|^2}\right)}$ $\operatorname{channel matrix}$

$$SINR = \frac{|s \cdot H \cdot g|^2}{N' + I}$$

$\mathbf{MIMO} \cdot \mathbf{SINR} = \mathbf{SINR}$

 SINR model adds the power of interferers

$$\frac{P_s}{N + \sum_{i \neq s} P_i} \ge \beta$$

 Superposition of principle (only) for electrical fields

$$P = \left(\sum_{i} E_{i}\right)^{2}$$

Independent interferences

$$\mathbb{E}\left[\sum_{i\neq s} E_i\right]^2 = \mathbb{E}\left[\sum_{i\neq s} |E_i|^2\right] = \mathbb{E}\left[\sum_{i\neq s} P_i\right]$$

Algorithms for Radio Networks Christian Schindelhauer

9


Power Gain

Communication with n sender and m receiver

• transmit power $P = \sum_i P_i = \text{const.}$


Signal power gain

- **SISO:** SINR_{1,1} = $\frac{P}{N+I}$
- MISO: SINR_{n,1} = $n \cdot SINR_{1,1}$
- **SIMO:** $SINR_{1,m} = m \cdot SINR_{1,1}$
- MIMO: SINR_{*n*,*m*} $\leq n \cdot m \cdot SINR_{1,1}$ (equality for rank(*H*) = 1)




Multipath Channel

Signal is reflected from obstacles




Multipath Channel

Signal is reflected from obstacles



Multipath Channels

- Level is sensitive to the locations
 - SNR varies a lost



Simple View of MIMO Encoding/Decoding

- ▶ 3 x 3 MIMO system
 - without noise

$$\begin{pmatrix} h_{11} & h_{12} & h_{13} \\ h_{21} & h_{22} & h_{23} \\ h_{31} & h_{32} & h_{33} \end{pmatrix} \begin{pmatrix} b_1 \\ b_2 \\ b_3 \end{pmatrix} = \begin{pmatrix} x_1 \\ x_2 \\ x_3 \end{pmatrix}$$

$$\left(\begin{array}{c}b_{1}\\b_{2}\\b_{3}\end{array}\right) = \left(\begin{array}{ccc}h_{11}&h_{12}&h_{13}\\h_{21}&h_{22}&h_{23}\\h_{31}&h_{32}&h_{33}\end{array}\right)^{-1} \left(\begin{array}{c}x_{1}\\x_{2}\\x_{3}\end{array}\right)$$

Problem: Noise

Channel adds noise

$$\begin{pmatrix} h_{11} & h_{12} & h_{13} \\ h_{21} & h_{22} & h_{23} \\ h_{31} & h_{32} & h_{33} \end{pmatrix} \begin{pmatrix} b_1 \\ b_2 \\ b_3 \end{pmatrix} = \begin{pmatrix} x_1 \\ x_2 \\ x_3 \end{pmatrix} + \begin{pmatrix} N_1 \\ N_2 \\ N_3 \end{pmatrix}$$

Noise will be also decoded

$$H^{-1}(x+N) = H^1Hb + H^{-1}N$$

= $b + H^{-1}N$

- Noise can be amplified
 - especially if Det[H] is small

Example

$$M = \begin{pmatrix} 0.9 + 0.1j & 0.9 - 0.1j & 0.4 + 0.2j \\ -0.2 + 0.3j & 1. + 0.4j & 0. - 0.2j \\ 1.8 + 0.25j & 1.9 - 0.2j & 0.8 + 0.4j \end{pmatrix}$$

▶ |Det[M]| = 0.0142...

$$M^{-1} = \begin{pmatrix} 86.0 + 29.6j & 3.1 - 0.7j & -42.6 - 14.3j \\ -5.2 - 43.0j & -0.3 - 1.5j & 2.9 + 21.3j \\ -126.0 + 70.4j & -3.1 + 5.7j & 62.6 - 35.7j \end{pmatrix}$$

- → $X = (1, -1, 1)^T$
- ► N = $(0.01, -0.01, -0.01)^{\mathsf{T}}$

$$M^{-1}(Mx+N) = \begin{pmatrix} 2.316 + 0.44i \\ -1.08 - 0.66i \\ -0.91 + 1.12i \end{pmatrix}$$

should be X!

Solution: Precode the signal

Instead of using b as original inputs

$$\begin{pmatrix} h_{11} & h_{12} & h_{13} \\ h_{21} & h_{22} & h_{23} \\ h_{31} & h_{32} & h_{33} \end{pmatrix} \begin{pmatrix} b_1 \\ b_2 \\ b_3 \end{pmatrix} = \begin{pmatrix} x_1 \\ x_2 \\ x_3 \end{pmatrix} + \begin{pmatrix} N_1 \\ N_2 \\ N_3 \end{pmatrix}$$

- Start with x and (pre-) code x $b = H^{-1}x$
 - then the resulting signal including noise is

$$Hb + N = H \cdot H^{-1}x + N = x + N$$

Example

$$M = \begin{pmatrix} 0.9 + 0.1j & 0.9 - 0.1j & 0.4 + 0.2j \\ -0.2 + 0.3j & 1. + 0.4j & 0. - 0.2j \\ 1.8 + 0.25j & 1.9 - 0.2j & 0.8 + 0.4j \end{pmatrix}$$
$$M^{-1} = \begin{pmatrix} 86.0 + 29.6j & 3.1 - 0.7j & -42.6 - 14.3j \\ -5.2 - 43.0j & -0.3 - 1.5j & 2.9 + 21.3j \\ -126.0 + 70.4j & -3.1 + 5.7j & 62.6 - 35.7j \end{pmatrix}$$
$$\star = (1, -1, 1)^{\mathsf{T}} \qquad b = \begin{pmatrix} 40.4 + 16.0i \\ -2.0 - 20.2i \\ -60.4 + 29.0i \end{pmatrix}$$

• received signal
$$Mb + N = \begin{pmatrix} 1.01 \\ -1.01 \\ 0.99 \end{pmatrix}$$

Rectangular Channel Matrices

- Pre-code the signal $b = H^{-1}x$
 - What to do if H is not a square matrix?
 - i.e. more sender than receiver antennas
- Use pseudo-inverse H⁺

$$H^{+} = (H^{*}H)^{-1}H^{*}$$

• where H* is the transposed complex conjugate of H


• i.e.
$$H^* = \overline{H}^T$$

Channel Capacity by Diversity Gain

- For maximum capacity it is necessary to know the Channel State Information (CSI)
 - for this the receiver feedback is necessary
- H⁺ may have large entries
 - this results in large amplification
- Use singular value decomposition of H
 - the maximum capacity can be computed by solving an optimization problem

Maximum Diversity Gain

- Given n sender antennas and m receiver antennas
 - the maximum diversity gain is **min**{n,m}
 - only if min{n,m} reflections are in different angles from senders and receivers





Algorithms for Radio Networks

MIMO

Albert-Ludwigs-Universität Freiburg Institut für Informatik Rechnernetze und Telematik Prof. Dr. Christian Schindelhauer



